

Coverings for presses in clothing factories

Suggestions without obligation - changes can be necessary for optimum result

General suggestions	Allgemeine Vorschläge
Poplin	Popeline
tinned copper wire screen #50, twill woven	verz. Kupferdrahtgewebe #50, Köper
stainless steel wire screen VM 231, very smooth	Edelstahldrahtgewebe VM 231, sehr glatt
Nylon-Stretch	Nylon-Stretch
V-Max Aramid-needlefelt V 209	V-Max Aramid-Nadelfilz V 209
VOMAPOR Silicone/foam, soft, 10 mm thick	VOMAPOR Silikon/Schaum, weich, 10 mm dick
REHAU foamed silicone Type 8042, grey, 8 mm	REHAU Schaumsilikon Type 8042, grau, 8 mm
Velvet fabrics	Samtartige Oberstoffe
tinned copper wire screen #50, twill woven	verz. Kupferdrahtgewebe #50, Köper
VOMAT bristle cover M 300 NO	VOMAT Borstenbezug M 300 NO
or V-Max Aramid-needlefelt V 209 + bristle cover M II	oder V-Max Aramid-Nadelfilz V 209+Borstenbezug M II
Nylon-Stretch	Nylon-Stretch
Polyester-needlefelt V 201	Polyester-Nadelfilz V 201
or Cotton molton M 4	oder Baumwoll-Molton M 4
VERDEX Super-Latexfoam	VERDEX Super-Latexschaum
V-Max Aramid-needlefelt V 209	V-Max Aramid-Nadelfilz V 209
REHAU foamed silicone Type 8090, red	REHAU Schaumsilikon Type 8090, rot
Soft padding	Weiche Polsterung
tinned copper wire screen #50, twill woven	verz. Kupferdrahtgewebe #50, Köper
VOMAPOR silicone/foam, soft, 6 mm thick	VOMAPOR Silikon/Schaum, weich, 6 mm dick
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
Nylon-Stretch	Nylon-Stretch
Nylon-Stretch	Nylon-Stretch
Polyester-needlefelt V 201	Polyester-Nadelfilz V 201
VERDEX Super-Latexfoam, 13 mm thick, perforated or VOMAPOR 100, lightred, 15 mm thick	VERDEX Super-Latexschaum, 13 mm, perforiert oder VOMAPOR 100, hellrot, 15 mm dick
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
REHAU foamed silicone Type 8090, red	REHAU Schaumsilikon Type 8090, rot