

# Coverings for presses in clothing factories

Suggestions without obligation - changes can be necessary for optimum result

Trouser presses	Hosenpressen
<b>Trouser presses (A)</b>	<b>Hosenpressen (A)</b>
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
Copper wire screen #60, smooth	Kupfer-Drahtgewebe #60, glatt
Multi-Stretch <i>or Nylon-Stretch</i>	Multi-Stretch <i>oder Nylon-Stretch</i>
Multi-Stretch <i>or Nylon-Stretch</i>	Multi-Stretch <i>oder Nylon-Stretch</i>
Polyester wire screen VM 219 <i>or Cotton molton M 4</i>	Polyester Drahtgewebe VM 219 <i>oder Baumwoll-Molton M 4</i>
VOMAPOR Silicone/foam, 10 mm thick <i>or Polyether foam, grey, 10 mm / 15 mm thick</i>	VOMAPOR Silikon/Schaum, 10 mm dick <i>oder Polyäther-Schaum, grau, 10 mm / 15 mm dick</i>
REHAU foamed silicone, 10 mm thick (Type 8012 yellow or Type 8090 red)	REHAU Schaumsilikon, 10 mm dick (Type 8012 gelb oder Type 8090 rot)
<b>Trouser presses (B)</b>	<b>Hosenpressen (B)</b>
VOMAPOR silicone/foam, soft, 6 mm thick	VOMAPOR Silikon/Schaum, weich, 6mm dick
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
Polyester wire screen mesh VM 219, twill woven	Polyester Drahtgewebe VM 219, Köper
Multi-Stretch	Multi-Stretch
Multi-Stretch	Multi-Stretch
Polyester wire screen mesh VM 219, twill woven	Polyester Drahtgewebe VM 219, Köper
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
VOMAPOR silicone/foam, soft, 6 mm thick	VOMAPOR Silikon/Schaum, weich, 6 mm dick
<b>Jeans presses</b>	<b>Jeanspressen</b>
tinned copper wire screen #50, twill woven	verz. Kupferdrahtgewebe #50, Köper
Polyester-Needlefelt V 201	Polyester-Nadelfilz V 201
Nylon-Stretch	Nylon-Stretch
Nylon-Stretch	Nylon-Stretch
Polyester-Needlefelt V 201	Polyester-Nadelfilz V 201
REHAU foamed silicone Type 8012, 10 mm thick	REHAU Schaumsilikon Type 8012, 10 mm dick
tinned copper wire screen #50, twill woven	verz. Kupferdrahtgewebe #50, Köper

# Coverings for presses in clothing factories

Suggestions without obligation - changes can be necessary for optimum result

Trousler presses	Hosenpressen
<b>Double leg trouser presses (A)</b>	<b>Doppelbein-Hosenpressen (A)</b>
tinned copper wire screen #50, twill woven	verz. Kupferdrahtgewebe #50, Köper
VOMAPOR silicone/foam, soft, 6 mm thick	VOMAPOR Silikon/Schaum, weich, 6 mm dick
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
Polyester wire screen mesh VM 219, twill woven	Polyester Drahtgewebe VM 219, Köper
Multi-Stretch (frame)	Multi-Stretch (Rahmen)
Multi-Stretch (frame)	Multi-Stretch (Rahmen)
Polyester wire screen mesh VM 219, twill woven	Polyester Drahtgewebe VM 219, Köper
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
VOMAPOR silicone/foam, blue, soft, 10 mm thick	VOMAPOR Silikon/Schaum, blau, weich, 10 mm
REHAU foamed silicone Type 8090, red, 10 mm	REHAU Schaumsilikon Type 8090, rot, 10 mm
tinned copper wire screen mesh #50, twill woven	verz. Kupferdrahtgewebe #50, Köper
Double leg trouser presses (B)	Doppelbein-Hosenpressen (B)
tinned copper wire screen #50, twill woven	verz. Kupferdrahtgewebe #50, Köper
VOMAPOR silicone/foam, supersoft, 6 mm thick	VOMAPOR Silikon/Schaum, supersoft, 6 mm dick
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
Nylon-Stretch	Nylon-Stretch
Multi-Stretch (frame)	Multi-Stretch (Rahmen)
Multi-Stretch (frame)	Multi-Stretch (Rahmen)
Nylon-Stretch	Nylon-Stretch
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
VOMAPOR silicone/foam with 60 mm central stripe	VOMAPOR Silikon/Schaum, mit Mittelstreifen
REHAU foamed silicone Type 8090, red, 10 mm	REHAU Schaumsilikon Type 8090, rot, 10 mm
tinned copper wire screen mesh #50, twill woven	verz. Kupferdrahtgewebe #50, Köper

# Coverings for presses in clothing factories

Suggestions without obligation - changes can be necessary for optimum result

Trousler presses	Hosenpressen
<b>Double leg trouser presses (C)</b>	<b>Doppelbein-Hosenpressen (C)</b>
tinned copper wire screen #50, twill woven	verz. Kupferdrahtgewebe #50, Köper
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
Nylon-Stretch	Nylon-Stretch
Multi-Stretch (frame)	Multi-Stretch (Rahmen)
Multi-Stretch (frame)	Multi-Stretch (Rahmen)
Nylon-Stretch	Nylon-Stretch
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
VOMAPOR 100 silicone/foam, lightred, 15 mm	VOMAPOR 100 Silikon/Schaum, hellrot, 15 mm
VOMAPOR silicone/foam, blue, hard, 6 mm	VOMAPOR Silikon/Schaum, blau, fest, 6 mm
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
tinned copper wire screen mesh #50, twill woven	verz. Kupferdrahtgewebe #50, Köper
<b>Seam opening presses</b>	<b>Pressen zum Nahtöffnen</b>
tinned copper wire screen #50, twill woven	verz. Kupferdrahtgewebe #50, Köper
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
V-Max Aramid-cover NO 16	V-Max Aramid-Bezug NO 16
Nylon-Stretch	Nylon-Stretch
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
REHAU foamed silicone Type 8052, pink, 6 mm	REHAU Schaumsilikon Type 8052, pink, 6 mm
tinned copper wire screen mesh #50, twill woven	verz. Kupferdrahtgewebe #50, Köper

# Coverings for presses in clothing factories

Suggestions without obligation - changes can be necessary for optimum result

Trousler presses	Hosenpressen
<b>Trouser topper presses (A)</b>	<b>Hosenbundpressen (A)</b>
tinned copper wire screen #50, twill woven	verz. Kupferdrahtgewebe #50, Köper
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
tinned copper wire screen mesh #50, twill woven	verz. Kupferdrahtgewebe #50, Köper
Nylon-Stretch	Nylon-Stretch
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
VOMAPOR 30 silicone/foam, yellow, 10 mm thick	VOMAPOR 30 Silikon/Schaum, gelb, 10 mm dick
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
VOMAPOR silicone/foam, blue, hard	VOMAPOR Silikon/Schaum, blau, fest
<b>Trouser topper presses (B)</b>	<b>Hosenbundpressen (B)</b>
brass wire screen mesh #50, twill woven, L to R	Messing-Drahtgewebe #50, Köper, L to R
brass wire screen mesh #50, twill woven, R to L	Messing-Drahtgewebe #50, Köper, R to L
brass wire screen mesh #50, twill woven, L to R	Messing-Drahtgewebe #50, Köper, L to R
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
brass wire screen mesh #50, twill woven, R to L	Messing-Drahtgewebe #50, Köper, R to L
brass wire screen mesh #50, twill woven, L to R	Messing-Drahtgewebe #50, Köper, L to R
Nylon-Stretch	Nylon-Stretch
VOMAPOR 30 silicone/foam, yellow, 15 mm thick	VOMAPOR 30 Silikon/Schaum, gelb, 15 mm dick
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
brass wire screen mesh #50, twill woven, R to L	Messing-Drahtgewebe #50, Köper, R to L
brass wire screen mesh #50, twill woven, L to R	Messing-Drahtgewebe #50, Köper, L to R
<b>Trouser topper presses (C)</b>	<b>Hosenbundpressen (C)</b>
tinned copper wire screen #50, twill woven	verz. Kupferdrahtgewebe #50, Köper
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
Nylon-Stretch	Nylon-Stretch
Nylon-Stretch	Nylon-Stretch
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
VERDEX Super-Latexfoam, perforated, 10 mm	VERDEX Super-Latexschaum, perforiert, 10 mm
V-Max Aramid-Needlefelt V 209	V-Max Aramid-Nadelfilz V 209
REHAU foamed silicone Type 8012, 6 mm thick	REHAU Schaumsilikon Type 8012, 6 mm dick
tinned copper wire screen #50, twill woven	verz. Kupferdrahtgewebe #50, Köper